Monitoring Platform Online Web Service

2019/07/23



Soft dB Inc. 1040, Belvedere Avenue, Suite 215 Quebec (Quebec) Canada G1S 3G3 Toll free: 1-866-686-0993 (USA and Canada) E-mail: <u>infoconsultation@softdb.com</u>





Contents

1	Intro	oductio	n	1
2	Logi	n		2
3	Mon	itoring	Platform Components	3
	3.1	Monit	oring Stations	3
	3.2	Monit	oring Sites	5
		3.2.1	Adding a Monitoring Site	6
		3.2.2	View Monitoring Data	7
4	Man	aging (Client Access	9
5	Mob	ile Con	npatibility	11

1 Introduction

The Soft dB Monitoring Platform allows optimizing your monitoring stations performance and improves the value of your monitoring data.

The Soft dB Monitoring Platform gives you the opportunity to start small and expand your capabilities as your business grows. Manage your entire monitoring station fleet from one screen and see what is happening remotely in the field. View the monitoring data in real-time as it gets recorded.

This manual describes how to use the Monitoring Platform. Contact Soft dB to open an account.

2 Login

Sign in to the Monitoring Platform by entering your username and password.



Many access levels are possible:

- Account Owner
 - Associated with invoicing
 - Views Monitoring Platform Credits
 - Can purchase Monitoring Credits
 - Can create site access
 - Can create site
 - Can request station subscription
- Administrator
 - Can create site access
 - Can create site
- Technician
 - Can view monitoring station status
 - Can view data
- Client
 - Can only view selected monitoring sites

3 Monitoring Platform Components

The Monitoring Platform is based on two principal components:

- Monitoring Station: A physical monitoring station
- Monitoring Site: A container for monitoring data

3.1 Monitoring Stations

The monitoring stations are physical instruments that upload their data to the monitoring platform. Their status can be assessed without being assigned to a monitoring site.

- Live sound level,
- Battery state of charge,
- Measurement status (running, idle),
- GPS coordinates.

Notification emails can be set for station events such as online/offline, low-battery, etc.

The monitoring stations are added to the account by Soft dB using the serial number.



The left part of the interface shows a list while the right part shows a map with the Monitoring stations.

Clicking on a Monitoring Station shows the context card with basic information. You can subscribe to the Monitoring Station notification emails by switching the "Subscribe" button ON.





On the station settings, you can set the station name and description. You can also view the current location of the station, force the location to a specific coordinate or set the location to its home base. Setting the location to its home base is useful when undeploying a monitoring station back to the office.

Soft dB ABC-Consulting						Ø MAPS	A CLIENTS	ALARMS	
Stations Maps >	NoiseWatch_3 > Settings								
Networkdu_1 (The field of the	on settings umber: PM0119051503		\checkmark	\sim	(😤 454 dB)				
NoiseWatch_2									
NnixWatch_3 (C 454.08) Gener	ral Settings	NoiseWatch_3	L.						
NoiseWatch_4									
Sites		Station Description	ption						
		Recipients							
		J Jonn O							
Loost	ion	Lathude							
Local	1011	36.248423							
		Longitude							
		-53.27 0455							
		Set	to Home	Force L	ocation				

Note that a user can select which monitoring station it wants to see:

Stations Maps > Stations NoiseWatch_1 Image of Stations NoiseWatch_2 Image of Stations NoiseWatch_2 Image of Stations NoiseWatch_3 Image of Stations NoiseWatch_4 Image of Stations Stats Image of Stations Image of Stations	Q, wWatch eWatch eWatch
Note-Hoad 1 Image: State 2 Search Image: State 2 Image: State 2 <th>Q, eWatch usWatch eWatch</th>	Q, eWatch usWatch eWatch
Noise/Watch_3 © 4.5 dB Imme Sarrial number Type Noise/Watch_4 © 4.0 dB Imme Sarrial number Noise/Watch_1 PM0111051501 Noise/Watch_2 State Imme Noise/Watch_2 PM0111051504 Noise/Watch_2 Noise/Watch_2 Noise/Watch_2 Noise/Watch_3 PM0111051503 Noise/Watch_2 Noise/Watch_2	eWatch eeWatch eeWatch
Noise/Watch_1 PM00119031501 Noise/Watch Sites Noise/Watch_2 PM0119031501 Noise/Watch Noise/Watch_3 PM0119051503 Noise/Watch	wWatch wWatch eWatch
Sites Noise/Watch_2 PM0119051504 Noise/Watch Noise/Watch_3 PM0119051503 Noise/Watch	eWatch .eWatch
NoiseWatch_3 PM0119051503 NoiseWatch	eWatch
NoiseWatch_4 PM0119051506 NoiseWatch	eWatch
Rows per page: 10 + 1-4 of a < >	

3.2 Monitoring Sites

The Monitoring Sites are container that holds the monitoring data for a specific location during a specific period. This concept allows deploying monitoring stations for time-restricted measurement campaign and redeploying the monitoring stations to another location without losing the data associated to the previous site.

Monitoring sites can be active (linked to a monitoring station) or inactive (not linked).



– Soft d B

3.2.1 Adding a Monitoring Site

- 1) Click on the "Add Site" button from the Sites view:
- 2) Enter a name for the site and a location (Pick on map or enter coordinates)

18		Site creation
Stations	Maya v line untrepr Ø Sites	Acme Industry P4
Sites	Septit	Description
	s	Select coordinates
	Acres Industry (*)	
	 Anna bokutty P2 Anna bokutty P1 Anna bokutty P1 	
	Same per page 10 +	1101
		7, 36,249423
		4-" YB.2/6485

3) Link the Monitoring Site to a Monitoring Station by selecting the station from the dropdown list.

dB ABC-Consulting			II MAPS	AL CLIENTS	ALARNS	
Былоть жоннийці Філіпі наменнийці Філіпі	Mage Are are non-you wont to list free extract Non-AN Site You NO	Ubload new site image CH005E FILE . The numeric de conducted e 1985				
Notomiach, s ((n. m. m.	General Settings demonstrate Acron Indust	ry P1				
States Annue (sakastig (1)	Station Dear	nption				
Aune Industry P2	et also falden e NasisetWater	3]			
	Location NeiseWatch NeiseWatch NeiseWatch	2 3 4				
		LOCATE ON MAP				



4) Load a picture of the monitoring site. Typically a view of the monitoring station in the environment:

dB ABC-Consulting		D MAPS & CLIENTS # ALAR	AS 🧖
Same Status G Gites Jame Status(17): ((((((((((((((((((((((((((((((((((((Maa → Acreintaty97 → Sintep Site Image	Upload flow size image 	
Anne beladry /2 (\$ 23.6) Anne beladry /2 (\$ 10.6)	General Settings	atry P1	
	Location 100.00		
	- Langtodi - 45 292241		

3.2.2 View Monitoring Data

Once the Monitoring site is created and linked to a Monitoring Station. The monitoring station will automatically upload the data to this site. To view the data, click on the Monitoring site on the map to show the context card and click on the "View Data" button







4 Managing Client Access

To add value to the Monitoring Data it's important to give access to the end user to the monitoring data. A client access gives a restricted access to a client only to selected monitoring sites.

On the Clients View, click on the "Add Client" button, enter the Name, User Name and Password. Note that the client can't change these parameters.



Once the client access is created, select the monitoring sites you wish to grant access to.

dB ABC-Consulting		II MAPS	A CLIENTS	ALARMS	
Acme Factory Acme Industry P1	Clients map → Client Settings				
Acres Industry P2 (🛜 🖽 4 (8)	Select which sites will be available for Acme Factory				
Acme Industry P3 (🛜 411 (8)	Search	Q,			
	Roms .				
	Acree Industry P1				
	Acme Industry P2 Acme Industry P3				
	Roes per page: 10 + 1.3 of 3	< ×			
CREATE CLIENT					

The selected sites will appear under the client name and will be shown on the map with a bounding rectangle. This rectangle represents the initial map view when the client logs in.



When the client logs in, it only sees the selected monitoring sites:



5 Mobile Compatibility

The Monitoring Platform interface is fully compatible with smaller mobile devices such as phone and tablets. The user can switch between the list view and the map view by using the button on the lower-right corner.

